## **BADGES**

## **Actual Pouch Sizes**

Select pouch size that will give you at least 1/8" border around your paper card. Leave room for the slot. Don't cover the slot with your paper insert.





